

ATTENTION!

Read this document prior to using your cellular camera!


QUICK START GUIDE to setup your Cellular Camera with Verizon Wireless.



Step 1) Before setting up your Verizon Wireless account be sure to turn on your camera and enter the setup information (including: time, date, temp, battery type).

Step 2) Download and Install the Security Settings software:
www.reconyx.com/software/securityview

Step 3) Program your cameras sending options using the "Security Settings" Software (See page 3 of the Cellular Camera Manual).



Step 1 – 3 are critical, as the camera will forward any text messages sent by Verizon to your email address during the account setup process.

Step 4) To activate your camera with Verizon Wireless you will need the MEID number printed on the label inside your camera.

Setup an Account with Verizon Wireless

Option 1

- Go to www.verizonwireless.com/activatedevice
- Enter your MEID number
- Follow the on-screen prompts to activate your camera



Option 2

- Call Verizon Wireless
- Consumer Sales at: (800) 256-4646
- Business Sales at: (800) 526-3178

Option 3

- Visit your local Verizon Wireless store

Step 5) Once your account is setup through Verizon, you will need to "Provision your Account" on your camera. **Go to: Change Setup > Cellular > Provision Modem** (See page 7 of the Cellular Camera Manual for additional information).

If you have any questions regarding the operation of your camera:
Call RECONYX Support at: 866-493-6064